

Notes for Windows XP installation of the Micrologger USB driver:

1.0 On a new fresh PC which has not been used with a USB Micrologger

- i. Connect the Micrologger system and switch on power
- ii. Cancel the 'Driver Wizard' window.
- iii. Run 'install.exe' from the driver section of your installation CD.
- iv. Press the install button and wait for the completion message.

2.0 On a PC which has been used with a USB Micrologger and has an old copy of the USB driver

- i. Connect the Micrologger system and switch on power
- ii. Run 'install.exe' from the driver section of your installation CD.
- iii. Press the install button and wait for the completion message.

In some cases you will have to uninstall the previous USB driver before carrying out 2.0 above. To uninstall the previous driver:

- i. Goto to 'Control Panel'
- ii. Double click 'System'
- iii. Click the 'Hardware' tab.
- iv. Click 'Device Manager'
- v. Make sure the Micrologger is switched on and connected and then click on the 'Jungo' class of devices.
- vi. The Micrologger should be shown as a device under Jungo. Right click on this and select uninstall.