



JUMPER CONFIGURATION FOR ICETOP

Annotated by NK  
10/13/2003

TP76  
A/B Jumper OFF

Termination Jumper

JP103 ON

JP2

Programming Jumper  
• to program Flash Memory  
• to program Configuration Memory

SET FOR CONFIG MEMORY  
(Allows either serial PROM or Flash to be programmed.)

RS-232 Power Jumper OFF

Maintenance Mode Jumper OFF

TP53

Alternate Termination Jumper OFF

JP7

JU16

Watchdog Jumper  
• Hardware Watchdog  
• Normal

SET FOR NORMAL

DOM Main Board Rev. 2 Jumper locations and configurations.

G. Przybylski July 30, 2003 Lawrence Berkeley National Laboratory  
for IceCube